



Fig. 1 Connection to the chimney

Optimum air humidity is needed to obtain good conditions in the room therefore it is recommended to use evaporators.

13. PRECAUTIONS

The wood heater cannot be operated under conditions increasing the risk of generating flammable gases, fire or explosion risk (e.g. laying a floor with an adhesive etc.).

- ~~Flammable (E) 3.7 (2.3.3012) 116 mber 10~~

DE

**Aufstell- und Bedienungsanleitung für den Dauerbranherd
FIKO 70
geprüft nach DIN EN 12815**

Z Á R U N Í L I S T

Název a typ výrobku: Sporák na pevná paliva

FIKO 70	typ F 1370	*)
FIKO 70A	typ F 1370 A	*)
FIKO 70 Nostalgia	typ F 1370 B	*)
FIKO 70 Nostalgia B	typ F 1370 H	*)

GARANCIALEVÉL